







## CREATE YOUR STYLE MINI PROJECTS HALLOWEEN 2012





MINI PROJECT "HALLOWEEN 2012"

## WITCHES HAT EARRINGS

## **Materials**

## SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Sew-on Stones	3700 (Marguerite Lochrose)	2 pcs.	10 mm	Jet	280
Sew-on Stones	3700 (Marguerite Lochrose)	2 pcs.	10 mm	Sun	248
Fancy Stones	4139 (Cosmic Ring)	2 pcs.	14 mm	Jet	280
Beads	5328 (XILION)	4 pcs.	2.5 mm	Jet	280
Beads	5328 (XILION)	6 pcs.	3 mm	Jet	280
Beads	5328 (XILION)	4 pcs.	4 mm	Jet	280
Beads	5540 (Artemis)	2 pcs.	12 mm	Jet	280
Beads	5714 (Star)	2 pcs.	8 mm	Jet	280

Supplies: 2 blank earwires TierraCast 90-5129-13

18" 24 gauge black Artistic Wire

## Instructions

- STEP 1: Cut the 12" piece of wire into 4 three inch pieces. Approximately 3 mm from the end of each piece of wire, use chain nose pliers to fold up a bend. (Note: using this technique you will create headpins.)
- STEP 2: Using two pieces of wire from step 1, slide on one Swarovski Sew-on Stone art. 3700 10 mm Jet, one Fancy Stone art. 4139 14 mm Jet, one Sew-on Stone art. 3700 10 mm Sun and one Bead art. 5540 12 mm Jet.
- STEP 3: Keep the two wires apart; on one wire slide on one Bead art. 5328 4 mm Jet. On the second wire, slide 3 Beads art. 5328 3 mm Jet and 2 Beads art. 5328 2.5 mm Jet. Cut the wire 10 mm from the last Bead art. 5328 2.5 mm Jet. Using round nose pliers, turn a loop towards the Bead art. 5328 2.5 mm Jet at least 1.5 to 2 rotations.

Continuation on next page



"Witches Hat Earrings", page 2

- STEP 4: Using the second wire that has the Bead art. 5328 4 mm Jet on it; turn a loop and then wrap the wire around the Bead art. 5328 4 mm Jet and create a wire wrap between the Bead art. 5328 4 mm Jet and the Bead art. 5540 12 mm Jet. Trim tail and tuck next to coil made.
- STEP 5: Attach one Bead art. 5328 4 mm Jet to a blank earwire. Turn a simple loop. Open loop and attach to the loop from step 4.
- STEP 6: Repeat steps 2 through 5 for the second side.
- STEP 7: OPTIONAL: Cut the 6" piece of wire into two equal pieces. Wire wrap Bead art. 5714 8 mm Jet and attach to the coiled loop made at the end of the Bead art. 5328 2.5 mm Jet. Repeat for the second side.
- STEP 8: Shape the point of the hat by gently curving the wire (see picture).



MINI PROJECT "HALLOWEEN 2012" CRYSTAL CORN EARRINGS

### Materials

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5328 (XILION)	24 pcs.	4 mm	Hyacinth	236
Beads	5328 (XILION)	26 pcs.	4 mm	Sunflower	292
Beads	5328 (XILION)	8 pcs.	4 mm	White Alabaster	281

Supplies: 2 blank earwires TierraCast 90-1120-00

3' 26 gauge silver Artistic Wire

## Instructions

- STEP 1: Cut wire into two equal pieces 18" long.
- STEP 2: Load onto one piece of wire 13 Swarovski XILION Beads art. 5328 4 mm Sunflower. Moving 6 Beads off to one side and keeping the 7 remaining Beads in the center of the wire, take the wire exiting from the 6 Beads and string the wire through all 7 Beads. (Note: the wire tails should be exiting in opposite directions from the 7 Beads. The 6 Beads should be sitting on top of and in between the 7 Beads art. 5328 Sunflower. It is important to keep tension on the wire when weaving.)
- STEP 3: String onto one of the wire sides, 5 Beads art. 5328 4 mm Hyacinth. Take the wire from the side with no Beads and string the wire through the 5 Beads. (Note: the wire tails should be exiting in opposite directions from the 5 Beads art. 5328 Hyacinth and the 5 Beads should be sitting on top and in between the 6 Beads art. 5328 Sunflower from the previous step.)
- STEP 4: Repeat step 3 using 4 Beads art. 5328 4 mm Hyacinth.
- STEP 5: Repeat step 4 using 3 Beads art. 5328 4 mm Hyacinth.
- STEP 6: Repeat step 5 using 2 Beads art. 5328 4 mm White Alabaster.
- STEP 7: Repeat step 6 using one Bead art. 5328 4 mm White Alabaster.

Continuation on next page



"Crystal Corn Earrings", page 2

- STEP 8: Take both tails of the remaining wire and working the wire together create a wire wrapped loop.
- STEP 9: Using one blank earwire, slip on one Bead art. 5328 4 mm White Alabaster. Turn a simple loop. Open the loop just made and add the finished piece from step 8.
- STEP 10: Repeat steps 2 through 9 for the second pair.

## CREATE YOUR STYLE with SWAROVSKI ELEMENTS

MINI PROJECT "HALLOWEEN 2012"

# TRIPLE CRYSTAL CORN PENDANT

## <u>Materials</u>

## SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5328 (XILION)	24 pcs.	3 mm	Hyacinth	236
Beads	5328 (XILION)	26 pcs.	3 mm	Sunflower	292
Beads	5328 (XILION)	6 pcs.	3 mm	White Alabaster	281
Beads	5328 (XILION)	24 pcs.	4 mm	Hyacinth	236
Beads	5328 (XILION)	26 pcs.	4 mm	Sunflower	292
Beads	5328 (XILION)	6 pcs.	4 mm	White Alabaster	281
Beads	5328 (XILION)	24 pcs.	5 mm	Hyacinth	236
Beads	5328 (XILION)	26 pcs.	5 mm	Sunflower	292
Beads	5328 (XILION)	6 pcs.	5 mm	White Alabaster	281

Supplies: 5' 26 gauge Artistic Wire

30" 0.5 mm leather

Continuation on next page



"Triple Crystal Corn Pendant", page 2

Instructions - 3 mm crystal corn pendant

- STEP 1: Cut a 12" piece of wire.
- STEP 2: Load onto wire 13 XILION Beads art. 5328 3 mm Sunflower from the SWAROVSKI ELEMENTS assortment. Moving 6 Beads off to one side and keeping the 7 remaining Beads in the center of the wire, take the wire exiting from the 6 Beads and string the wire through all 7 Beads. (Note: the wire tails should be exiting in opposite directions from the 7 Beads. The 6 Beads should be sitting on top and in between the 7 Beads. It is important to keep tension on the wire when weaving.)
- STEP 3: String onto one of the wire sides, 5 Beads art. 5328 3 mm Hyacinth. Take the wire from the side with no Beads and string the wire through the 5 Beads. (Note: the wire tails should be exiting in opposite directions from the 5 Beads art. 5328 Hyacinth and the 5 Beads should be sitting on top and in between the 6 Beads art. 5328 Sunflower from the previous step.)
- STEP 4: Repeat step 3 using 4 Beads art. 5328 3 mm Hyacinth.
- STEP 5: Repeat step 4 using 3 Beads art. 5328 3 mm Hyacinth.
- STEP 6: Repeat step 5 using 2 Beads art. 5328 3 mm White Alabaster.
- STEP 7: Repeat step 6 using 1 Beads art. 5328 3 mm White Alabaster.
- STEP 8: Take both tails of the remaining wire and working the wire together create a wire wrapped loop. Set aside.

Instructions - 4 mm crystal corn pendant

- STEP 1: Cut an 18" piece of wire.
- STEP 2: Load onto wire 3 Swarovski XILION Beads art. 5328 4 mm Sunflower, the 3 mm crystal corn pendant made above and 10 Beads art. 5328 4 mm Sunflower. Moving 6 Beads off to one side and keeping the 7 remaining Beads in the center of the wire, take the wire exiting from the 6 Beads and string the wire through all 7 Beads. (Note: the wire tails should be exiting in opposite directions from the 7 Beads. The 6 Beads should be sitting on top and in between the 7 Beads. It is important to keep tension on the wire when weaving.)
- STEP 3: String onto one of the wire sides, 5 Beads art. 5328 4 mm Hyacinth. Take the wire from the opposite side and string through the 5 Beads. (Note: the wire tails should be exiting in opposite directions from the 5 Beads art. 5328 Hyacinth and the 5 Beads should be sitting on top and in between the 6 Beads art. 5328 Sunflower from the previous step.)
- STEP 4: Repeat step 3 using 4 Beads art. 5328 4 mm Hyacinth.
- STEP 5: Repeat step 4 using 3 Beads art. 5328 4 mm Hyacinth.
- STEP 6: Repeat step 5 using 2 Beads art. 5328 4 mm White Alabaster.

Continuation on next page



"Triple Crystal Corn Pendant", page 3

Instructions - 4 mm crystal corn pendant

- STEP 7: Repeat step 6 using one Bead art. 5328 4mm White Alabaster.
- STEP 8: Take both tails of the remaining wire and working the wire together create a wire wrapped loop. Set aside.

## Instructions - 5 mm crystal corn pendant

- STEP 1: Using the remaining wire, load onto wire 4 Swarovski XILION Beads art. 5328 5 mm Sunflower, the 4 mm crystal corn pendant made above (with the 3 mm pendant attached) and 9 Beads art. 5328 5 mm Sunflower. Moving 6 Beads off to one side and keeping the 7 remaining Beads in the center of the wire, take the wire exiting from the 6 Beads and string the wire through all 7 Beads (and pendant). (Note: the wire tails should be exiting in opposite directions from the 7 Beads. The 6 Beads should be sitting on top and in between the 7 Beads. It is important to keep tension on the wire when weaving.)
- STEP 2: String onto one of the wire sides 5 Beads art. 5328 5 mm Hyacinth. Take the wire from the opposite side and string through the 5 Beads. (Note: the wire tails should be exiting in opposite directions from the 5 Beads art. 5328 Hyacinth and the 5 Beads should be sitting on top and in between the 6 Beads art. 5328 Sunflower from the previous step.)
- STEP 3: Repeat step 2 using 4 Beads art. 5328 5 mm Hyacinth.
- STEP 4: Repeat step 3 using 3 Beads art. 5328 5 mm Hyacinth.
- STEP 5: Repeat step 4 using 2 Beads art. 5328 5 mm White Alabaster.
- STEP 6: Repeat step 5 using one Bead art. 5328 5 mm White Alabaster.
- STEP 7: Take both tails of the remaining wire and working the wire together create a wire wrapped loop.
- STEP 8: String the leather through the loop on top of the 5 mm crystal corn. Make an overhand knot with the tails of the leather.

CREATE YOUR STYLE with SWAROVSKI ELEMENTS

## MINI PROJECT "HALLOWEEN 2012"

## TRICK OR TREAT NECKLACE

## <u>Materials</u>

## SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Flat Backs No Hotfix	2058 (XILION Rose)	2 pcs.	SS10	Light Siam	227
Sew-on Stones	3700 (Marguerite Lochrose)	1 pc.	10 mm	Jet	280
Sew-on Stones	3700 (Marguerite Lochrose)	1 pc.	10 mm	Sun	248
Fancy Stones	4139 (Cosmic Ring)	8 pcs.	14 mm	Jet	280
Beads	5328 (XILION)	2 pcs.	2.5mm	Jet	280
Beads	5328 (XILION)	3 pcs.	3 mm	Jet	280
Beads	5328 (XILION)	91 pcs.	4 mm	Jet	280
Beads	5328 (XILION)	6 pcs.	4 mm	Hyacinth	236
Beads	5328 (XILION)	6 pcs.	4 mm	Sunflower	292
Beads	5328 (XILION)	6 pcs.	4 mm	White Alabaster	281
Beads	5328 (XILION)	12 pcs.	5 mm	Hyacinth	236
Beads	5328 (XILION)	13 pcs.	5 mm	Sunflower	292
Beads	5328 (XILION)	3 pcs.	5 mm	White Alabaster	281
Beads	5540 (Artemis)	1 pc.	12 mm	Jet	280
Beads	5714 (Star)	1 pc.	8 mm	Jet	280
Pendants	6902 (Zinnia)	1 pc.	16.5x25mm	Jet	280

Supplies: 1 TierraCast toggle set 94-6151-13 15 TierraCast round jump rings 01-0020-13 2 3 mm crimp covers 6" 24 gauge black Artistic Wire Two-part epoxy glue

6 TierraCast oval jump rings 01-0018-13 2 2x2 crimp beads 20" 0.015 Beadalon Stringing Wire 24" 26 gauge silver Artistic Wire

Continuation on next page



"Trick or Treat Necklace", page 2

## Instructions - Bat Pendant Drop

- STEP 1: Mix two-part epoxy glue as instructed on package.
- STEP 2: Using a toothpick, place 2 small dots of mixed glue near center of Pendant art. 6902 Jet from the SWAROVSKI ELEMENTS assortment (see picture for correct way to lay Pendant).
- STEP 3: Apply a small amount of beeswax to the end of a clean toothpick. Pick up one Flat Back No Hotfix art. 2058 Light Siam using the tip of the beeswax toothpick and place on one of the glue dots. Repeat with second Flat Back No Hotfix art. 2058 Light Siam.
- STEP 4: Allow glue to dry for recommended time on glue package. Clean any glue residue with a Q-tip dipped in acetone.
- STEP 5: Open 5 round jump rings and 2 oval jump rings.
- STEP 6: Attach one round jump ring to bat and close. Attach two round jump rings to Swarovski Fancy Stone art. 4139 Jet and close. Repeat for second Fancy Stone and set aside.
- STEP 7: Using the oval jump ring attach to round ring on bat and one round ring on Swarovski Fancy Stone. Close ring. Using second oval jump ring attach the two Fancy Stones together by connecting the round jump rings. Set this pendant aside.

## Instructions - Crystal Corn Pendant Drop

- STEP 1: Using the 24" gauge wire, load onto wire 13 Beads art. 5328 5 mm Sunflower from the SWAROVSKI ELEMENTS assortment. Moving 6 Beads off to one side and keeping the 7 remaining Beads in the center of the wire, take the wire exiting from the 6 Beads and string the wire through all 7 Beads. (Note: the wire tails should be exiting in opposite directions from the 7 Beads. The 6 Beads should be sitting on top and in between the 7 Beads. It is important to keep tension on the wire when weaving.)
- STEP 2: String onto one of the wire sides, 5 XILION Beads art. 5328 5 mm Hyacinth. Take the wire from the opposite side and string through the 5 Beads. (Note: the wire tails should be exiting in opposite directions from the 5 Beads and the 5 Beads should be sitting on top and in between the 6 Beads art. 5328 5 mm Sunflower from the previous step.)
- STEP 3: Repeat step 2 using 4 Beads art. 5328 5 mm Hyacinth.
- STEP 4: Repeat step 3 using 3 Beads art. 5328 5 mm Hyacinth.
- STEP 5: Repeat step 4 using 2 Beads art. 5328 5 mm White Alabaster.
- STEP 6: Repeat step 5 using one Bead art. 5328 5 mm White Alabaster.
- STEP 7: Take both tails of the remaining wire and working the wire together create a wire wrapped loop.
- STEP 8: Open 6 round jump rings and 3 oval jump rings.

Continuation on next page



"Trick or Treat Necklace", page 3

Instructions - Crystal Corn Pendant Drop

- STEP 9: Attach two round jump rings to Fancy Stone art. 4129 Jet and close. Repeat for other two Fancy Stones and set aside.
- STEP 10: Using the oval jump ring attach the corn to one round jump ring on a Fancy Stone and close. Using second oval jump ring attach the two Fancy Stones together by connecting to the round jump rings. Repeat for third Fancy Stone and set this pendant aside.

Instructions - Witches Hat Pendant Drop

- STEP 1: Cut the 6" piece of wire into two 3" pieces. Approximately 3mm from the end of each piece of wire, use chain nose pliers to fold up a bend. (Note: using this technique you will create headpins.)
- STEP 2: Using two pieces of wire from step 1, slide on one Sew-on Stone art. 3700 10 mm Jet, one Fancy Stone art. 4139 14 mm Jet, one Sew-on Stone art. 3700 10 mm Sun and one Bead art. 5540 12 mm Jet.
- STEP 3: Keep the two wires apart; on one wire slide on one Bead art. 5328 4 mm Jet. On the second wire, slide 3 Beads art. 5328 3 mm Jet and 2 Beads art. 5328 2.5 mm Jet. Cut the wire 10 mm from the last Bead art. 5328 2.5 mm Jet. Using round nose pliers, turn a loop towards the Bead art. 2.5 mm Jet at least 1.5 to 2 rotations.
- STEP 4: Using the second wire that has the Bead art. 5328 4 mm Jet on it; turn a loop and then wrap the wire around the Bead art. 5328 4 mm Jet and create a wire wrap between the Bead 5328 4 mm Jet and the Bead art. 5540 12 mm Jet. Trim tail and tuck next to coil made.
- STEP 5: OPTIONAL: Using a 3" piece of wire, wire wrap Bead art. 5714 8mm Jet and attach to the coiled loop made at the end of the Bead art. 5328 2.5mm Jet.
- STEP 6: Shape the point of the hat by gently curving the wire (see picture).
- STEP 7: Open 4 round jump rings and 1 oval jump ring.
- STEP 8: Attach one round jump ring to the loop on the witches hat and the Fancy Stone and close. Attach another round jump ring to the Fancy Stone and close. Attach two round jump rings to second Fancy Stone art. 4139 14 mm Jet and close.
- STEP 9: Using an oval jump ring attach the two Fancy Stones together by connecting the round jump rings. Set this pendant aside.

Continuation on next page



"Trick or Treat Necklace", page 4

## Instructions - Necklace

- STEP 1: Using beading wire string on 40 Swarovski XILION Beads art. 5328 4 mm Jet, one Bead art. 5328 4 mm White Alabaster, one Bead art. 5328 4 mm Hyacinth, one Bead art. 5328 4 mm Sunflower, one Bead art. 5328 4 mm Jet.
- STEP 2: Add bat pendant drop. Add one XILION Bead art. 5328 4 mm Jet, one Bead art. 5328 4 mm Sunflower, one Bead art. 5328 4 mm Hyacinth, one Bead art. 5328 4 mm White Alabaster, 2 Beads art. 5328 4 mm Jet, one Bead art. 5328 4 mm White Alabaster, one Bead art. 5328 Hyacinth, one Bead art. 5328 4 mm Sunflower and one Bead art. 5328 4 mm Jet.
- STEP 3: Add candy corn pendant drop. Add one XILION Bead art. 5328 4 mm Jet, one Bead art. 5328 4 mm Sunflower, one Bead art. 5328 4 mm Hyacinth, one Bead art. 5328 4 mm White Alabaster, two Beads art. 5328 4 mm Jet, one Bead art. 5328 4 mm White Alabaster, one Bead art. 5328 4 mm White Alabaster, one Bead art. 5328 4 mm Sunflower and one Bead art. 5328 4 mm Jet.
- STEP 4: Add witches hat pendant drop. Add one Bead art. 5328 4 mm Jet, one Bead art. 5328 4 mm Sunflower, one Bead art. 5328 4 mm Hyacinth, one Bead art. 5328 4 mm White Alabaster, and 40 Beads art. 5328 4 mm Jet.
- STEP 5: Using crimp bead and one half of toggle clasp crimp closed. Repeat for other side.
- STEP 6: Attach crimp covers.

CREALE OUR STYLE with SWAROVSKI ELEMENTS

SPOCKY TREES CHARM BRACELET

### **Materials**

### SWAROVSKI ELEMENTS

Product Group	Article No.	Amount	Size	Color	Color Code
Beads	5040 (Briolette)	4 pcs.	6mm	Crystal Red Magma	001 REDM
Beads	5040 (Briolette)	3 pcs.	8mm	Jet	280
Beads	5328 (XILION)	4 pcs.	4 mm	Crystal Red Magma	001 REDM
Beads	5328 (XILION)	5 pcs.	4 mm	Jet	280
Beads	5540 (Artemis)	3 pcs.	17 mm	Crystal Red Magma	001 REDM
Beads	5540 (Artemis)	4 pcs.	12 mm	Jet	280
Beads	5601 (Cube)	7 pcs.	4 mm	Jet	280

- Supplies: 1 TierraCast Lady Skeleton 94-2317-12 1 TierraCast Cat 94-2147-61 1 TierraCast Coffin 94-2323-12 10 24 gauge 2" headpins 6 4 mm open jump rings
- 1 TierraCast Man Skeleton 94-2316-12
- 1 TierraCast flat Skeleton Charm 94-2320-12
- 1 TierraCast Skull 94-5685-12
- 1 lobster clasp
- 7" open link chain

## Instructions

- STEP 1: Using a head pin load on one Swarovski Bead art. 5328 4 mm Jet, one Bead art. 5040 6 mm, one Bead art. 5040 Red Magma, one Bead art. 5540 12 mm Jet, and one Bead art. 5328 4 mm Jet. Repeat 3 more times and set aside.
- STEP 2: Using a head pin load on one Bead art. 5601 4 mm Jet, one Bead art. 5040 8 mm Jet, one Bead art. 5540 17 mm Crystal Red Magma, and one XILION Bead art. 5328 4 mm Crystal Red Magma. Repeat two more times and set aside.
- STEP 3: Using a head pin load on one skeleton head bead. Repeat one more time and set aside.
- STEP 4: Using a head pin load on one Bead art. 5328 4 mm Jet and one Bead art. 5328 4 mm Crystal Red Magma. Set aside.

Continuation on next page



## "Spooky Trees Charm Bracelet", page 2

- STEP 5: Open all jump rings and add to each charm.
- STEP 6: Working from the same side of chain wire wrap the tree components and skull components from steps 1-3 at desired intervals.
- STEP 7: Working from the same side of the chain attach charms with open jump rings at desired intervals.
- STEP 8: At one end of the chain add lobster clasp with open jump ring.
- STEP 9: At opposite end of chain using an open jump ring attach open cat charm. Using XILION Beads from Step 4 wire wrap onto same link as cat charm.